


Easy Open Extra Wide Gate

MODEL NO: 1185

Owner's Manual





READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF GATE.

KEEP INSTRUCTIONS FOR FUTURE USE.

www.regalo-baby.com

Regalo International, LLC.

3200 Corporate Center Drive, Suite 100 Burnsville, MN 55306-9803, USA Toll Free: 866-272-5274

Assembly and Installation Instructions
Please read these instructions carefully before installing your gate.

∆WARNING:

Intended for young children aged 6 months through 24 months. Check the gate regularly to see if all the hardware and mountings are tightened.

To prevent serious injury or death, securely install gate or enclosure and use according to manufacturer's instructions. Never use with a child able to climb over or dislodge the gate or enclosure.

Never leave child unattended.

Use only with the locking/latching mechanism securely engaged.

IMPORTANT:

Please follow these instructions carefully to ensure that your gate extension is properly installed. Improper installation could result in the gate becoming dislodged from the doorway, or unstable. Always make sure the extension is securely attached to the gate before using. The safety of your child is your responsibility.

Note:If using this gate at the top of stairs, the 4 Wall Cups MUST be used. If not use, the gate could be dislodged from the opening.


It is preferable to install the extension on the hinge side of the gate. If you have an application that requires additional extensions, please contact the retailer which you purchased your gate from.

This gate can be used in openings from 29 inches to 50 inches.

Contact Regalo for questions and replacement parts. If in doubt about the use of your gate, call our customer care line 866-272-5274.

Regalo International, LLC. 3200 Corporate Center Drive, Suite 100 Burnsville, MN 55306-9803, USA.

Check to make sure you have all of the parts shown:




- A. Easy Open Gate
- **B.** 6" Extension
- C. 12" Extension
- **D.** 4 Threaded Spindle Rods
- **E.** 4 Wall Mounting Cups
- **F.** 4 Screws (requires a Phillips/crosshead screwdriver)

Assembling and Installing Your Gate

**Note: IMPORTANT!! You will notice a slight gap between the gate door and the gate frame. THIS IS NOT A DEFECT. Your gate is a pressure mounted gate and this gap will disappear once you tighten your gate in its opening.


Step 1.

Locate the 4 threaded spindle rods. Rotate the adjustment wheels along the threading, eliminating the gap between the adjustment wheel and the rubber foot.




Step 2.

Insert the 4 threaded spindle rods into the holes at each of the 4 corners of the gate as shown in the Diagram



Step 3.

Position the gate so that it is level and centered within your doorway or opening. Rotate the adjustment wheels on the threaded spindle rods in the opposite direction as in Step 1, expanding the gap between the rubber foot and the adjustment wheel. Expand each of the 4 Threaded Spindle Rods until they make contact with the doorway or opening. Do not fully tighten the Threaded Spindle Rods yet.




HINT: It may be necessary to hold the Threaded Spindle Rods or Rubber Feet while rotating the Adjustment Wheels to ensure the entire unit does not rotate.

Step 4.

When you are satisfied with the general placement of your gate, fully tighten the Threaded Spindle Rods attached to the lower corners of the gate by further rotating the Adjustment Wheels.

Continue by tightening the upper Threaded Spindle Rods. As you tighten the upper Threaded Spindle Rods, you will notice the gap between the Door Frame and the door begin to narrow.

In order for the gate to function properly, tighten the upper Threaded Spindle Rods completely without removing the Plastic Lock Spacer. Then, pull the Thumb Lock back to remove the Plastic Lock Spacer. This will ensure proper spacing between the door and frame.




There should be equal spacing among each of the 4 Threaded **NOTE:** Spindle Rods. Make the appropriate adjustment to ensure you have installed your gate safely.

Positioning and Attaching the Wall Cups

Your gate is a pressure mounted gate. Therefore, it is not necessary to use the screw attached Wall Cups in your door opening if you choose not to. However, IF YOU ARE USING THE GATE AT THE TOP OF STAIRS YOU MUST USE THE WALL CUPS. Using the Wall Cups will affix your gate more firmly in the doorway or opening.

Step 1.

After you have mounted your gate, and you are satisfied with its positioning, use a pencil or other marking tool to draw a circle on the surface of your doorway or opening around the perimeter of the 4 rubber feet.




Step 2.

Next, completely remove the gate from the opening by loosening each of the 4 Threaded Spindle Rods and de-pressurizing the gate.

Step 3.


With the gate fully removed, you can now use the circles you marked during Step 1 as guides for screwing in your 4 Wall Cups.

Center each of the Wall Cups within the guide circles and use the provided self-tapping screws to fasten them in place via the hole through the center of each Wall Cup.



Step 4.


Reinstall your gate in the doorway or opening according to the instructions, using the newly installed Wall Cups as anchoring points for the 4 Threaded Spindle Rods



Operating the Door Latch


Step 1.

Use your thumb or forefinger to pull back on the Thumb Lock. This action will release the locking pin below the metal saddle that joins the door and the gate frame.



Step 2.


With the Thumb Lock pulled back, lift up on the entire door panel, raising the gate high enough for the upper and lower metal saddles to clear free of their counterparts. Your gate door should now be free to fully open. To close the gate, simply repeat these steps in reverse.



HINT:

If your latch is not properly engaging, ensure that your gate is level, mounted properly, and that you have not over-tightened the Threaded Spindle Rods.

Adding a Gate Extension



- **Step 1.** Assemble the gate per the gate instructions.
- **Step 2**. Choose the side of the gate to be extended and remove the top and bottom Threaded Spindle Rods.
- **Step 3.** Assemble the gate and extension as illustrated.
- **Step 4.** Reposition the gate and fit in accordance with the gate fitting instructions.

Removing Your Gate From The Wall

To remove your gate from the wall, rotate the Adjustment Wheels on each of the 4 Threaded Spindle Rods to depressurize the gate from its doorway or opening. Then, gently pull or push the gate free from its doorway or opening.

Care And Maintenance

Periodically check the gate for signs of damage, wear, or missing components. Do not use if any part is missing, worn or damaged. Check the gate regularly to ensure all the hardware and mountings are tightened. Do not use abrasive cleaners or bleach. Clean by sponging with warm water and a mild detergent.

90 Days Limited Warranty:

If, during the first 90 days after consumer purchase of the item, under reasonable and non-commercial use and conditions of maintenance, it fails while owned by the original purchaser because of the quality of materials or workmanship of finish and assembly, Regalo International LLC will replace or repair it at Regalo's option. PROOF OF PURCHASE REQUIRED.


Replacement Parts Available

In the event of any damage or breakage, the following replacement parts are available for order by contacting Regalo Customer Service.



Wall Cups
(#14015)


1" Wall Mount Screws
(#10001)




Threaded Spindle Rods with Adjustment Wheel (#14016)



Bottom Plug Insert B (#14041)



Tapered Round Insert



Untapered Round Insert
(#14043)

Contact Regalo for questions and replacement parts. For questions about the use of your gate, call our customer care line 866-272-5274.

Regalo International, LLC. 3200 Corporate Center Drive, Suite 100 Burnsville, MN 55306-9803, USA



Regalo International, LLC.

3200 Corporate Center Drive, Suite 100 Burnsville, MN 55306-9803, USA Toll Free: 866-272-5274